



CRUZ Performance E85 Rated Fuel Line Kit Install Procedure

1. Put 45 ends from hoses on pump hanger.
2. Run both lines across to driver side following factory feed lines.
3. Continue over rear end down to filter.
4. Just in front of stock filter mine will go attach straight -8 Fitting
(Make sure to put arrow facing forward on the filter)
5. Attach straight -8 to fuel filter and continue forward with both lines up frame rail to master cylinder.
6. Cut across back of motor and come down valve cover/intake side.
7. Straight -6 into regulator for return.
8. Bring -8 around the front of the motor to 45 into fuel rail



CRUZ Performance
505 N Falkenburg Rd Suite B
Tampa, FL 33619
813-399-0409
don@cruzperformance.com